



Wiring diagram of the Foot Controller - Wireless foot controllers used for
MODEL PRO 500 (DC 310), MODEL PRO 700 (DC 350), DC 240, DC 290, DL 210, DL 270, DL 290, DL 320, DL 330, DL 340, DL 380,
MODEL PRO 600 (DA 270), DA 280, MODEL PRO 800 (DA 370), DA 380
 (30.4.2021)

Foot Controller UNO



Foot Controller NOK



Back of FC_PREM_TKW1

